





"Made in Fujitec"

Fujitec is Creating and Leading the New Global Standard for Elevators



By manufacturing safe and reliable elevators in-house, we are building trust with people around the world.

Fujitec's "Global Common Components" are used in the REXIA-D brand. The quality of components, such as traction machines, elevator controllers, and operating fixtures, is controlled through Fujitec's integrated system of global quality management. Elevators with the same high quality will be provided by Fujitec's global supply chain under the concept of "Made in Fujitec."



# **Excellent Performance**

The permanent magnetic synchronous gearless motors, which have been designed and developed by Fujitec, provide the utmost reliability and excellent driving performance. These motors reflect 75 years of accumulated know-how through our technological achievements in elevator manufacturing, which spans from product designing to fabrication.

# **Reliable Operation**

Since all control-related components, ranging from control circuits to inverters, were independently developed by Fujitec, highly reliable elevator operation is established. In the event of an elevator malfunction, the elevator control system assembled with our components immediately detects the malfunction and maintains efficient and stable operation.

# **Universal Design**

Under our universal designs, aesthetically refined buttons, displays, etc. on elevator operating fixtures are highly visible. Passengers will have a superb and comfortable riding experience.

# **Styles**

Various decoration styles for the elevator interior and landing floors are offered by Fujitec.

Customers can select the most suitable decorative materials for car panels, car ceilings, car floorings, car operating boards and landing fixtures.





# **CONTENTS**

Excellent Performance05
Reliable Operation 06
Universal Design 07
Styles 09
Systems & Functions 25
Planning 29
Relevant Dimensions 33
Power Supply Data 34
Work Done by Others 35


# **Excellent Performance**

# **Gearless Traction Machine with Permanent Magnetic Synchronous Motor**

The gearless traction machine with a permanent magnet synchronous motor assure high riding comfort quality and low power consumption. This newly adopted technology reduces the weight and size of a traction machine, because gears are no longer required for elevator speed control.

# **No Elevator Machine Room Results** in Space Saving

Our REXIA-D elevator requires no machine room space. This remarkable feature results in a reduction of building construction cost and allows building architects to maximize floor design without needing to factor in machine rooms of conventional elevator.






# **Ultra-Slim Door Operator with Permanent Magnetic Synchronous Motor**

Fujitec's new door operators have adopted a permanent magnetic synchronous motor which doesn't have any gears for door speed control. The use of this kind of motor reduces the size of a door operator and achieves smooth and precise door operation.


These new door operators consume approximately

35% less power than the conventional ones.

## **Distributed Control System**







hall lanterns.


The bus system is employed for data transmission between microcomputers located in every hall-call fixture, car operating board, and control panel. This bus system has strong protection against signal interference and has system-extending capability.

An elevator operation system with multiple microcomputers makes maximum use of the "Distributed Control System." Hall indicators, car operating boards, and control panels incorporate high-performance microcomputers. These independent microcomputers analyze elevator operating conditions utilizing self-diagnostic functions and implement immediate control of elevator operations. Also, data transmission buses among microcomputers increase data processing capability.










# **Reliable Operation**



# FLEX-NX series - Elevator Group Supervisory Control System -

Fujitec has adopted the "Virtual Passenger Optimization Method" as a new elevator group control system.

This system controls elevator group operation by virtually calculating passenger waiting time in advance based on past accumulated data, such as passenger travel patterns and passenger volume at each floor. Also, this method comprehensively calculates passenger waiting time based on extrapolated data of probable future passengers, how many passengers will come to a certain floor when a hall call is registered and/or how many passengers will come to a certain floor when no hall call is registered. This comprehensive analysis reflects whole building traffic conditions for efficient elevator operation control as well as reducing daily passenger waiting time by up to 10%.



# **Universal Design**




Fujitec's new global-standard operating fixtures reflect the latest in Human Engineering technology.

Fixture buttons with clearly visible lettering function as the man-machine interface. Passengers can register their destination in a visually intuitive manner.

23569

23569



# **Night-Time Self-Checking Operation**

- A safety enhancement for increased reliability -

Mechanical brake conditions are automatically checked by moving the elevator during the night time while not receiving any car and hall calls.


This night-time self-checking operation increases passenger safety and contributes to a high after-sales product quality.

# **IONFUL**

- Plasmacluster™ Ion Generating Device -

## (Optional Specification)

Fujitec is the leading elevator company to have installed a Plasmacluster lon generating device in an elevator. This device built in a car's ventilation unit disinfects airborne mold, bacteria, viruses, allergens, and odor molecules as well as creating clean air in the elevator which enhances passenger comfort.



# **Multi-Beam Sensor**

Multi-beam Sensor emits multiple infrared beams, creating an invisible curtain covering the doorway. If any of the beams is interrupted, the closing doors will stop and reopen. This function results in a significantly higher detection rate of a passenger and/or an object in the doorway.



# **LED Down Lights on Car Ceiling**

For car ceiling lighting, Fujitec adopts LED downlights, which are long-lasting and energy-efficient. This adoption contributes to the protection of the environment.

Lifetime	approx. 1,500 hours	approx. 20,000 hours	approx. 13 times
Wattage	90W	9W	1/10(one-tenth)



# **VONIC** (Automatic Voice Announcement System)

(Optional Specification)

A computerized voice system (English) provides passengers with timely information about car directions, car arrivals, door opening and closing, and emergencies, etc.

[At the customer's request, announcements in other languages can be added.]







 $^{\prime}$  .

**STYLES Standard Car Design Optional Car Design** 



CE-g1
Paint Finished Steel Sheet

(TE-a7) Walls,Transom &Door: Paint Finished Steel Sheet (TE-a7)

Cross-Flow Fan

Car Operating Board: (FX-h1) Stainless Steel with

Floor: BD-b2

Sill: Stainless Steel



BD-b1





BD-b3



BD-b4



BD-b5





BD-b7



BD-b8



Stainless Steel with Hairline Finish (Frame) Stainless Steel with Mirror Finish (Central)
Stainless Steel with Hairline Finish
Cross-Flow Fan
FX-k11
Designed PVC (BD-C1)
Stainless Steel



Ceiling: (CE-e2)	Paint Finished Steel Sheet (TE-f1)
Walls,Transom &Door:	Stainless Steel with Hairline Finish
Mirror:	Stainless Steel with Mirror Finish
Fan:	Cross-Flow Fan
Handrail:	HR-a1
WCOB:	FX-g31
Floor:	Designed PVC (BD-C1)
Sill:	Stainless Steel

Optional Car Design Optional Car Design



Ceiling: (CE-c1)	Paint Finished Steel Sheet (TE-f1)
Walls,Transom &Door:	Stainless Steel with Hairline Finish
Fan:	Cross-Flow Fan
Floor:	BD-b5
Sill:	Stainless Steel



Ceiling:	Stainless Steel with Hairline Finish (Frame)
(CE-e4)	Stainless Steel with Mirror Finish (Central)
Walls(CR-f2):	
Side Panel:	Steel Panel with Wooden Decorative Plate(Sides Stainless Steel with Mirror Finish(Centra)
Rear Panel:	Steel Panel with Wooden Decorative Plate(Sides) Patterned Glass + Light Strip (Centra)
Front Panel, Transom :	Stainless Steel with Hairline Finish
Fan:	Cross-Flow Fan
Floor:	Designed PVC (BD-C1)
Sill:	Stainless Steel

Steel Panel with Wooden Decorative Plate





Ceiling: (CE-g5)	Stainless Steel with Mirror Finish
Walls(CR-f1): Side & Rear Panels: Wall's Centra Panels: Front Panel,Transom:	Steel Plate with Laminated Sheet(TE-g1; Stainless Steel with Mirror Finish Stainless Steel with Sandblast Finish
Door:	Stainless Steel with Sandblast Finish
Fan:	Cross-Flow Fan
Floor:	Designed PVC (BD-b8)
Sill:	Stainless Steel
Kick Plate:	Stainless Steel with Hairline Finish



Ceiling: (CE-e2)	Stainless Steel with Mirror Finish
Walls(CR-f1): Side & Rear Panels: Wall's Centra Panels: Front Panel,Transom:	Steel Plate with Laminated Sheet(TE-g2) Stainless Steel with Mirror Finish Stainless Steel with Sandblast Finish
Door:	Stainless Steel with Sandblast Finish
Fan:	Cross-Flow Fan
Floor:	Designed PVC (BD-b6)
Sill:	Stainless Steel
Kick Plate:	Stainless Steel with Hairline Finish

1

# **Optional Car Design**



Ceiling: (CE-c5)	Paint Finished Steel Sheet (Dark Gray with Sand Texture)
Walls(CR-f3):	
Side Panels:	Light Gray Satin Coated Steel Plate Black Satin Coated Steel Plate
Rear Panel:	Light Gray Satin Coated Steel Plate Black Satin Coated Steel Plate Mirror
Front Panel, Transom:	Stainless Steel with Mirror Finish
Fan:	Cross-Flow Fan
Floor:	BD-b6
Car Operating Board:	FX-k13
Sill·	Aluminum Allov



Ceiling:	Stainless Steel with Hairline Finish (Frame)
(CE-e4)	Stainless Steel with Mirror Finish (Central)
Walls(CR-f4):	
Side Panels:	Steel Plate with Laminated Sheet(TE-g1)
Rear Panel:	Stainless Steel with Mirror Finish (Two sides), Stainles Steel with Mirror Etching Finish (Central)
Front Panel, Transom :	Stainless Steel with Hairline Finish
Fan:	Cross-Flow Fan
Floor:	Designed PVC (BD-e1)
Sill:	Aluminum Alloy



## CE-g1

Flat Panel: Steel Sheet with Color Paint Light: LED (White) Emergency Light (1W, LED)



## CE-g5

Flat Panel: Steel Sheet with Color Paint

Light :

Downlight (10W, LED) Emergency Light(1W,LED)



## CE-c1

Arch-Shaped Part:
Milky-White Acrylic Sheet
Flat Part:
Steel Sheet with Color Paint
Light:
LED+ Downlight(3W, LED)
Emergency Light(5W, LED)



## CE-e4

Frame Part:

Stainless Steel with Hairline

Central Part:

Stainless Steel with Mirror Milky-White Acrylic Sheet

Light:

LED( White)+ Downlight( 2W, LED) Emergency Light( 4.5W, LED)



## CE-c7

Flat Part: Milky-White Acrylic Sheet Flat Panel: Steel Sheet with Color Paint Light: LED (White) Emergency Light(5W,LED)



## CE-e5

Flat Panel: Milky-White Acrylic Sheet

Flat Panel:

Paint Finished Steel Sheet
- Dark Gray with Sand Texture


Light: LED (White)



## CE-c4

Arch-Shaped Part:
Milky-White Acrylic Sheet
Flat Part:
Steel Sheet with Color Paint
Light:
LED (White)

Emergency Light(5W,LED)



Design of CE-e2 for Deep Car: The layout rotate by 90°.

# CE-e2

Arch-Shaped Part: Milky-White Acrylic Sheet

Flat Panel:

Steel Sheet with Color Paint

\_ight:

LED (White)+ Downlight(3W, LED) Emergency Light(4.5W, LED)

(In case of deep car, the design of ceiling will be changed.)







Optional

Note: Ceiling internal height will vary based on the ceiling types.





Faceplate: Stainless Steel with Hairline Finish Indicator:

Orange Dot-Matrix LED Buttons: Push buttons

**FX**-h12





Faceplate: Stainless Steel with Hairline Finish Indicator: Buttons: Push buttons

**FX**-h11



Optional Background

Faceplate: Stainless Steel with Hairline Finish Indicator: Multicolor LCD Screen (7 inch) Buttons: Push buttons

# **Wall-mounted Type**

















**FX**-h71









0



0



Optional





0





**FX**-h72





Stainless Steel with Hairline Finish/ Acrylic Resin

Orange Dot-Matrix LED

Push buttons

Multicolor LCD Screen (4.2 inch) Monochrome LCD (4.1 inch) Buttons:

15. 16.






Faceplate: (Swing Type) Stainless Steel with Hairline Finish

Indicator: Orange Dot-Matrix LED

Buttons: Push buttons **FX**-k11



Faceplate: (Swing Type)
Stainless Steel with Hairline Finish
Indicator:
Multicolor LCD Screen (10.4 inch)
Buttons:

Push buttons

**FX**-k12

**FX**-k13



Faceplate: (Swing Type)
Stainless Steel with Hairline Finish
Indicator:
Monochrome LCD Screen (7 inch)
Buttons:
Push buttons

# **Inserted Box Type**























































18.

#### Faceplate:

Stainless Steel with Hairline Finish

#### Indicator:

Orange Dot-Matrix LED Multicolor LCD Screen (4.2 inch) Monochrome LCD (4.1 inch)

Buttons: Push buttons

Standard Optional

Faceplate: (Swing Type)

Indicator:

Buttons:

Push buttons

Stainless Steel with Hairline Finish

Multicolor LCD Screen (7 inch)





















































19.







**FX**-n44





The surface of stainless steel is nano-anti-fingerprint treatment, which realizes the anti-fingerprint effect and greatly improves the anti-dirty.

#### Faceplate:

Fingerprint Resistant Sandblasted Stainless Steel

Indicator:

Multicolor LCD Screen (4.3 inch) Monochrome LCD (5.0 inch)

**Buttons:** 










**CP**-D3 Stainless Steel Button with Braille Dots When Pressed: Light Emitting Part: Ring Lighting Color: Orange

Faceplate:	Stainless Steel with Hairline Finish
Buttons:	Stainless Steel Button



## **Button**







<b>CP</b> -D5	
Type:	Stainless Steel Button with Braille Dots
Ring & Number emits light:	Slight white light when standby, strong white light when answering.



RP-D1

Туре:	Stainless Steel Button
When Pressed:	Light Emitting Part: Ring
Lighting Color:	Orange



RP-D3

Туре:	Stainless Steel Button with Braille Dots
When Pressed:	Light Emitting Part: Ring
Lighting Color:	Orange



RP-E4

Type:	Glass Button
Square &	Slight white light when
Number emits	standby, blue light when
light:	answering.



CP-D1

Stainless Steel Button
Light Emitting Part: Ring
Orange

## Handrail



HR-a1 Stainless Steel Hairline Plate



**HR**-b1 & b2 Stainless Steel Hairline Tube/ Stainless Steel Mirror Tube

# **Hall Fixtures**



22


**Landing Design Color Samples** 





TE-g1 BD-b1 **BD**-b5

**Group Supervisory Control** 



\*The scale and color of an actual design differs

from the images.

# **Systems & Functions**



#### 1. Elevator Operation Control System

Control Systems	Details of the Systems
For One Elevator: 1-Car Selective Collective Operation (Simplex)	Landing calls in the direction in which the elevator is traveling are served sequentially. After all the landing calls are served, landing calls in the opposite direction will be served. When there are no incoming calls, the elevator stops and stays at the last served floor.
For Two Elevators in a Bank: 2-Car Selective Collective Operation (Duplex)	Two selective-collective-operation elevators work together in one group. Landing calls are served by either elevator that can respond first. When there are no calls, one will be on standby at the main floor; the other will stay at the last served floor.
For Three to Four Elevators in a Bank (Group Control Operation)	The operation of more than two elevators in a bank is controlled by a group supervisory system which calculates passenger waiting time in advance based on the accumulated traffic data, such as passenger travel patterns and passenger volume at each floor, etc.

#### 2. Functions and Specific-Purpose Operations, etc.

	Functions and urpose Operations, etc.	Details	●: Standard / ■: Optional
	Alarm Buzzer	When the emergency button is pressed, the car-top-mounted buzzer will sound an alarm.	•
	Rescue Operation to the Nearest Floor	In the event that an elevator stops between floors, a safety circuit will automatically analyze the situation and slowly move the elevator to the nearest available floor.	•
	Automatic Releveling	In the event that an elevator floor isn't leveled with the landing floor, the Automatic Releveling function will initiate and make the elevator floor flush with the landing floor.	•
	Emergency Car Lighting	In the event of a power failure, a self-charging-battery-equipped emergency lighting system will light up the elevator for passenger safety and relief.	•
	Five-Way Intercom	An intercom for 5-way communication is installed in the elevator. It allows 4 remote telephones to communicate with the elevator; one on the car top, one in the pit, one in the machine room and one in the building-system control room.	•
Passenger-Safety Functions	Multi-Beam Sensor	A multi-beam sensor emits multiple infrared beams, which will scan at the high speed in the elevator door, forming an infrared beam barrier. If a single beam is interrupted, the sensor will stop the closing doors and reopen them.	•
	Multi-Beam Sensor with Mechanical Safety Edge	A multiple-beam sensor can be incorporated in mechanical safety edges of elevator doors.	•
	Night-Time Self-Checking Operation	During the night time when the elevator doesn't receive any car and hall calls, the system will move the elevator and check the mechanical brake conditions automatically.	•
	Open Door Warning	If a passenger tries to forcibly open the doors while the elevator is in operation, the warning device will sound an alarm.	•
	Unintended Car Movement Protection (UCMP)	The Unintended Car Movement Protection system prevents elevator movement from the landing floor, while passengers are entering and getting off the elevator.	•
	Car Door Anti Stripping Device	It can prevent passengers from falling into the hoistway when the door is opened in the non- unlocking area, and further ensure the safety of elevator passengers.	•
	Impact Resistant Door System	The impact resistance of the landing door system is further strengthened, and the risk of falling into the hoistway caused by the impact of the landing door system is effectively prevented, further ensuring the safety of elevator related personnel.	•

The above functions may change without prior notice.

# **Systems & Functions**

	Functions and urpose Operations, etc.	Details	•: Standard / ■: Optional
	Anti-Nuisance Function	1) For elevators with three or more landings, when three or more car calls are registered at the same time, or when four or more car calls are registered in an extremely short period of time, the system will automatically cancel the activated car calls.  2) For elevators with five or more landings, when an elevator loaded with 100 kg or less receives four or more car call registrations, the system will cancel all the activated registrations.	•
	Auto Adjustment of Door Open Time	This function automatically adjusts the door-hold open time (dwell time) at each floor depending on passengers' hall- and car- call registration situations.	•
	Automatic Return to Main Floor (for 1-Car & 2-Car & Group Control Operation)	When an elevator does not receive any car- or hall- calls for a certain period of time, the Automatic Return to Main Floor function makes the elevator go to the lobby or a predetermined floor and waits in standby for passengers to board.	•
	Door Nudging	If the car doors are held open over a given period of time, the Door Nudging function will close them slowly with an audible alarm.	•
Efficient-Operation Functions	Auto-Separation after Elevator Failure (for Group Control Operation)	When an elevator under group control operation fails to operate normally, it will be separated from the elevator group so as not to affect the overall group elevator performance.	•
	Load Bypass	When a traveling car is fully loaded, it will bypass floors where hall calls are registered. Those hall calls will be assigned to another available elevator.	-
	Overload Warning	When a car becomes overloaded, the warning alarm will sound. The elevator doors will not close until the overloaded state is resolved.	•
	Reverse-Direction Car-Call Cancellation	In the event that a passenger tries to register a car call that is behind the car's current travelling direction, the elevator system will regard it as a nuisance call and ignore it in order to maintain the elevator service efficiency.	•
	Wrong Car-Call Register Cancellation	In case a passenger presses the wrong car call button, this mistake can be cancelled by pushing the same button twice.	•
	Door Open Holding Button (COB)	In order to meet the demand of loading and unloading goods, a door opening extension button is installed on the operation panel in the car. Pressing this button can keep the door opening time for 3 minutes.	•
	Arrival Chime (In Car)	When a car arrives at a destination floor, an arrival chime will sound softly.	-
	Attendant Operation	By using attendant-operation buttons inside a car operating board's cabinet, authorized personnel can register car calls for in-car passengers. In addition to monitoring incoming hall calls, the attendant decides the car travel direction and operates the car doors with priority service for in-car passengers.	•
Passenger-	Automatic Voice Announcement System (VONIC)	A computerized voice system provides passengers with timely information about car directions, car arrivals, door opening and closing, and emergencies, etc. At the customer's request, announcements in other languages can be added.	
Comfort Functions	Plasmacluster™ Ion Generating Device (IONFUL)	Plasmacluster Ion Generating Device to be built into a car's ventilation unit creates clean air for passenger comfort by disinfecting germs, odor molecules, bacteria, viruses, and allergens in the elevator.	•
	Visual Display on Car Operating Board	Informing on an elevator's current condition, a visual display on the car operating board will provide passengers with timely text messages such as "OVERLOADED", "EMER. OPERATION", "PLEASE EXIT THE ELEVATOR." etc.	•
	Visual Display on Landing Fixture	Informing on an elevator's current condition, a visual display on the landing fixture will provide waiting passengers with timely text messages such as "OVERLOADED", "EMER. OPERATION", etc.	•

	nctions and pose Operations, etc.	Details	•: Standard / ■: Optional
	Automatic Fan and Light Control	If an elevator receives no car- and hall- calls within a certain period of time, its ventilation fan and lights will turn off automatically.	•
Energy- Saving Functions	Elevator Operation Period Control	The elevator operation period in a day is automatically controlled by a timer mounted on the control panel's computer board in the machine room.	-
	Parking Operation	When an elevator is shifted to Parking Operation mode, the elevator will move to the pre-assigned floor and park with its doors closed, and car lights and fan turned off.	-
	Battery-Powered Automatic Landing Operation (LANDIC)	In the event of a power failure, a compact battery power source will move the car to the nearest available floor.	•
	Door Opening Failure Rescue Operation	When an elevator fails to open the doors at a landing floor, it will move to the next available floor and open them.	•
	Earthquake Rescue Operation (WAVIC)	When a seismic sensor has detected a seismic wave (the secondary seismic wave), the elevator(s) will be shifted to rescue operation mode and automatically move to the nearest available floor for passenger evacuation.	
Specific-Purpose Operations	Fire Operation	In the event of a fire, the Fire Operation mode will automatically take an elevator directly to an refuge floor and immobilize it there. (One refuge floor at the terminal floor)	•
	Fireman Operation	Under automatic operation, when the Fireman's switch is on, the car will immediately cancel all the calls and run to the refuge floor. The elevator responds to the call in the car only, which is used for special fire fighting operation.	
	Independent Operation	By turning on the Independent Operation buttons (EXCL) inside a car operating board's cabinet, the elevator only responds the car-calls, and does not respond the hall-calls.	•
	Standby Power Operation	In the event of a power failure, the elevator(s) will return to an refuge floor using standby power and will be held there on standby. * Standby power system shall be provided and installed by third parties.	•
	Elevator Visual Monitoring System (ELVIC)	By monitoring the current status of running elevators and giving necessary commands to elevators through desk-top PCs in a specific remote location, ELVIC manages and controls elevator operation.	
Equipment for Building Security, etc.	CCTV-Camera Cables	To meet the needs of video capture or digital signal transmission such as surveillance cameras in the car, the elevator is equipped with dedicated transmission cables from the COP to the car, which can respond to various transmission schemes according to the needs of the building party.	•
	Elevator Operation Supervisory Panel (such as watching board, console panel, etc.)	Through an elevator operation supervisory panel, the status of elevator operation can be monitored and controlled.	•
	Building-Management-System (BMS) Interface	Through a purpose-built interface, a building management system can receive up-to-date elevator operation data.	•


The above functions may change without prior notice.

# Planning


## 1600Kg, 2000kg 2-Panel Right Side Opening Door (2SR)

# Inserting Mortar and Surface Finish ( By Others) S Width of the jamb


( left Side of the Narrow Jamb)



(Right Side of the Narrow Jamb)




(left Side of the Wide Jamb)




(Right Side of the Wide Jamb)

## 800-2000Kg 2-Panel Center Opening(2CO)




Narrow Jamb




Wide Jamb

#### Note: The above dimensions are for reference only. The actual engineering design data shall be used.

## Standard Specification (Wall-Mounted Type)




## Optional Specification (Inserted Box Type)




Note 1: The above dimensions are for reference only. The actual engineering design data shall be used.


Capacity (kg)		800 (Deep Car)	<b>1000</b> (Wide Car)	<b>1000</b> (Deep Car)	<b>1200</b> (Wide Car)	<b>1200</b> (Deep Car)	<b>1350</b> (Wide Car)	<b>1350</b> (Deep Car)	<b>1600</b> (Wide Car)	<b>1600</b> (Deep Car)	<b>2000</b> (Wide Car)	<b>2000</b> (Deep Car)
L1(mm)	885	760	1010	775	1150	825	1245	825	1300	1140	1470	1220

# Planning







800kg, 1000kg Wide Car




1200kg~ 2000kg Wide Car




Hoistway Plan 800kg, 1000kg Deep Car





1200kg, 1350kg Deep Car



<sup>\*1.</sup> The above dimensions are for reference only. The actual engineering design data shall be used.
\*2. The above dimensions are based on RC-structure hoistway.
\*3. The above hoistway's internal dimensions are based on the hoistway with waterproof finish.
\*4. If hoistway's internal dimensions are too large, intermediate beams shall be provided and installed by others based on Fujitec-submitted drawings.
\*5. The required thickness of the hoistway's structural walls is 150mm or more (not including the thickness of wall finish).

# **Relevant Dimensions**

## Wide Car

Capacity	Speed	Opening	Car Inside A x B	Opening W x H	Hoistway X x Y	Pit Depth	Overhead OH	Pit Reaction(kN)						
(kg)													R4	
	1.0					1280	CPH+1380							
	1.5				1985×1700	1370	CPH+1500							
800	1.75	2CO	1350x1400	800x2100	1982X1100	1420	CPH+1590	100	84	52	52	71	49	
	2.0					1500	CPH+1700							
	2.5				2050x1700	1700	CPH+1950							
	1.0					1280	CPH+1380							
	1.5				2200x1700	1370	CPH+1500					78		
1000	1.75	2CO	O 1600x1400	900×2100		1420	CPH+1590	116	96	56	56		53	
	2.0				2250x1700	1600	CPH+1700							
	2.5				2230X1700	1750	CPH+1950							
	1.0					1340	CPH+1400	67						
	1.5			1100×2100		1490	CPH+1580		100					
1200	1.75	200	1800×1500		2550x1810	1540	CPH+1700			72	72	113	76	
	2.0					1600	CPH+1800							
	2.5					1800	CPH+2000							
	1.0					1450	CPH+1400							
	1.5				2650x1810	1570	CPH+1580			78				
1350	1.75	2CO	2000×1500	1100×2100		1700	CPH+1680	77	126		78	124	83	
	2.0				2700x1810	1700	CPH+1800							
	2.5				2750x1810	1900	CPH+2000							
	1.0					1450	CPH+1400							
	1.5				2755x1900	1600	CPH+1580							
1600	1.75	2CO	2100×1600	1100×2100		1700	CPH+1680	94	155	83	83	130	91	
	2.0				2800x1900	1700	CPH+1800							
	2.5				2000X1900	1900	CPH+2000							
	1.0					1450	CPH+1450							
	1.5					1650	CPH+1580							
2000	1.75	2CO 2350x1700	1200×2100	3050x2000	1720	CPH+1680	107	173	92	92	144	102		
	2.0					1720	CPH+1800							
	2.5					1900	CPH+2000							

#### Deep Car

peeh c	aı													
Capacity														
(kg)													R4	
	1.0					1280	CPH+1380							
	1.5					1370	CPH+1500							
800	1.75	2CO	1100×1800	800×2100	1860×2100	1420	CPH+1590	100	84	52	52	71	49	
	2.0					1500	CPH+1700							
	2.5					1700	CPH+1950							
	1.0					1280	CPH+1380							
	1.5					1370	CPH+1500							
1000	1.75	2CO	1100x2100	900x2100	1950x2400	1420	CPH+1590	116	96	56	56	78	53	
	2.0					1600	CPH+1700							
	2.5					1750	CPH+1950							
	1.0					1340	CPH+1400							
	1.5					1490	CPH+1580							
1200	1.75	2CO	) 1300x2100	900x2100	2000×2400	1540	CPH+1700	67	100	72	72	113	76	
	2.0					1600	CPH+1800							
	2.5					1800	CPH+2000							
	1.0					1450	CPH+1400							
	1.5				2000x2600	1570	CPH+1580							
1350	1.75	2CO	1300x2300	900x2100	2000X2000	1700	CPH+1680	77	126	78	78	124	83	
	2.0					1700	CPH+1800							
	2.5				2050x2600	1900	CPH+2000							
	1.0					1450	CPH+1400							
	1.5					1600	CPH+1580							
1600	1.75	2SL	1400x2400	1200×2100	2200x2770	1700	CPH+1680	94	155	83	83	130	91	
	2.0					1700	CPH+1800							
	2.5					1900	CPH+2000							
	1.0					1450	CPH+1450							
	1.5					1650	CPH+1580							
2000	1.75	2SL	1500x2700	1200x2100	2270×3080	1720	CPH+1680	107	173	92	92	144	102	
	2.0					1720	CPH+1800							
	2.5					1900	CPH+2000							

Notes: 1. The data shown above may vary based on elevator specification arrangement.

- Refer to the Work Done by Others for the Acceptable Inclination of Hoistway's Vertical Centerline.
- 3. The standard car panel height is 2350mm.
- 4. The standard thickness of car return panel is 55 mm. It can be increased to 90 mm for the beautiful appearance with free cost, the precondition is that the depth size of hoistway and machine room should be added 35mm based on above.

# **Power Supply Data**

Capacity (kg)																	
(1.6)																	
	1.0	5.2	19	28	7	8	20	343	468	613	830	1073	1506	1807	2119	2575	2711
	1.5	7.8	27	43	9	11	32	237	323	423	573	740	1039	1247	1463	1777	1871
800	1.75	9	30	48	9	12	32	217	296	388	526	679	953	1144	1342	1631	1717
	2.0	10.4	34	57	10	14	40	191	260	341	462	597	837	1005	1179	1432	1508
	2.5	13.6	41	74	12	16	50	157	214	280	380	491	690	828	971	1179	1242
	1.0	6.5	23	33	9	9	25	281	383	502	680	878	1233	1480	1735	2109	2220
	1.5	9.7	32	50	10	13	40	198	270	354	480	620	870	1044	1225	1488	1567
1000	1.75	11.4	35	55	11	15	40	182	249	326	442	571	802	962	1129	1372	1444
	2.0	13	39	64	12	16	40	162	221	290	393	507	712	854	1002	1218	1282
	2.5	17	54	95	16	20	63	119	162	213	288	373	523	628	736	895	942
	1.0	8.2	27	40	11	11	32	235	320	419	568	734	1031	1237	1451	1763	1856
	1.5	12.2	40	62	13	15	40	162	221	289	392	507	711	853	1001	1216	1280
1200	1.75	14.2	45	73	14	17	50	141	192	251	341	440	618	742	870	1057	1113
	2.0	16.3	51	84	15	20	63	126	172	225	305	395	554	665	780	948	998
	2.5	19.5	59	103	17	22	63	109	148	194	264	341	478	574	673	818	861
	1.0	9.6	30	45	12	12	32	211	287	377	510	659	926	1111	1303	1583	1667
	1.5	13.7	45	72	15	17	50	143	195	256	347	448	629	755	886	1076	1133
1350	1.75	16	48	78	15	19	50	132	181	237	321	414	582	698	819	995	1048
	2.0	18	56	94	17	22	63	114	156	204	276	357	502	602	706	858	903
	2.5	22.3	70	129	21	25	80	91	124	162	220	284	399	479	561	682	718
	1.0	10.9	33	46	13	14	40	197	269	352	477	616	865	1039	1218	1480	1558
	1.5	16.2	49	74	16	20	50	129	177	231	314	405	569	683	801	974	1025
1600	1.75	19	54	83	16	22	63	118	162	212	287	371	521	625	733	891	938
	2.0	21.8	59	94	17	25	63	106	144	189	257	332	466	559	656	797	839
	2.5	27.2	77	131	21	31	80	83	113	148	200	259	364	437	512	622	655
	1.0	13.6	38	54	16	16	40	166	227	297	403	521	731	877	1029	1250	1316
	1.5	20.4	61	90	20	24	63	104	142	186	252	325	457	548	643	781	822
2000	1.75	23.8	67	101	20	28	80	95	129	169	230	297	417	500	587	713	751
	2.0	27.2	74	116	21	31	80	85	116	153	207	268	376	451	529	643	677
	2.5	34	96	159	26	38	100	0	90	118	160	207	291	349	409	497	524

Notes: 1. The data shown above may vary based on elevator specification arrangement.

2. Earthing wires shall be arranged and installed based on local elevator code requirement.

# **Work Done by Others**

## 1. Elevator Hoistway Environment

Hoistway Temperature	Hoistway temperature shall be kept from 5 °C (41 °F) to 40 °C (104 °F).
	1. When a temperature reaches at 40 °C (104 °F), the relative humidity does not go beyond 50%.
Relative Humidity	2. In the year's most humid month(s), relative humidity shall be kept lower than 90 % and the temperature lower than 25°C (77 °F).
	Dew condensation prevention measures shall be taken, if there are the possibilities that condensation form inside and on electrical equipment.

#### 2. Electric Power Source

Type of Power Supply		Three-Phase Power Supply for Elevator Driving Machine     Single-Phase Power Supply for Lighting Equipment
	Allowable Error of Voltage Value	The allowable error of voltage value is 7 % above and below the rated voltage.

## 3. Acceptable Inclination of Hoistway's Vertical Centerline

Hoistway's Vertical Length	Centerline's Tilt away from the Plumb Line (unit: mm)
30 meter or less	0 to 25 mm or less
more than 30 m up to 60 m or less	0 to 35 mm or less
more than 60 m	0 to 50 mm or less

4. Work done by Others
The following items are in the scope of other contractors' work, not covering all items done by them.

#### For Hoistway

1.	Construct solid-state, fire-proof elevator hoistway.	
2.	Cut out landing walls for Fujitec's installation of elevator operating fixtures and elevator equipment.	
3.	Do wall finishing work by filling cement between jambs and landing walls.	
4.	Do wall finishing work by filling cement between landing fixtures and landing walls.	
5.	Give water-proofing and drainage treatment in elevator pit including the installation of pumping equipment.	
6.	Install space divider screens between respective elevators in a hoistway pit.	
7.	Install steel separator beams at regular vertical intervals in a hoistway.	
8.	When hoistway is constructed with bricks, put steel lintels in its walls for Fujitec's installation of rail brackets. The steel lintels must be completely fixed inside the walls. The vertical height of the lintel is required to be 300 mm or more. For details, see the relevant drawings.	

	9.	When an elevator traveling distance from a floor to the next is more than 11 m, make an opening on the hoistway wall between the floors and install emergency exit doors in the opening for passenger evacuation.
	10.	It is advised that there is no human access to the space below the hoistway pit.
	11.	When the bottom of a hoistway pit is deeper than the required level, add backfill concrete up to the required level.
	12.	Provide and install a pit ladder based on the layout drawings.
	13.	Provide and install a power switching / distributing board in the hoistway.
	14.	Provide and install electrical pipes, wires, and leads in the hoistway. They shall be extended from the power switching / distributing board to the controller, machine, and their related apparatuses.
	15.	Provide and install all of electricity supply apparatuses (inclusive of pipes, leads, wires, etc.) on various routes from the building's electricity supply system to the hoistway, landing floors and Fujitec-designated locations.
	16.	Install air ventilator(s) and/or air conditioner(s) in order to keep the hoistway temperature between 5 °C (41 °F) and 40 °C (104 °F).
	17.	Provide and install electrical outlets inside the hoistway.
	18.	Install lighting equipment of 30 watt or more at 7-meter intervals inside the hoistway with 0.5-meter clearance at the top and bottom of the hoistway. The lighting intensity is required to be 50 lux or more at the car-top working platform and at the 1-meter high position above the pit bottom.
	19.	Make holes in the walls of a hoistway for Fujitec's installation of machine support beams and fill concrete into the gap between the walls and the fixed beams.
	20.	Cut out landing walls and install emergency operation panels for Fujitec's emergency access to and operation of elevator machine and brake.
	21.	Install machine lifting hooks and / or beams on the hoistway's ceiling slabs. The required lifting load capability is stated on the relevant installation drawings.
	1.	Ground-fault circuit interrupter and current leakage alarm are required to be protected against current-harmonic distortion.
	2.	Lay building's telecommunication lines 500 mm away from the electric feeder lines for elevator system.
	3.	Remove corroded metal materials from the hoistway.
	4.	Protect the hoistway against hazardous gas.
	5.	Prevent dust from accumulating in the hoistway.
	6.	Provide a storage room in order to stock elevator parts and installation materials.
	7.	Do not place any tools and materials not related to elevators in the hoistway.
-		

# **Fujitec Global Operations**



Ohio Plant (USA)



Langfang Plant (China)



Korea Plant





Taiwan Plant (China)



Big Wing (Group Headquarters in Japan, Elevator Plant) India Plant



Singapore Plant





**FUJITEC VENEZUELA C.A.** 






FUJITEC AMERICA..INC. FUJITEC CANADA..INC. FUJITEC VENEZUELA C.A. FUJITEC ARGENTINA S.A. FUJITEC URUGUAY S.A.

#### Japan

FUJITEC CO.,LTD.



#### **East Asia**

FUJITEC (HK) CO., LTD. FUJITEC TAIWAN CO.,LTD. FUJITEC KOREA CO.,LTD. HUASHENG FUJITEC ELEVATOR CO.,LTD. SHANGHAI HUASHENG FUJITEC ESCALATOR CO..LTD. FUJITEC SHANGHAI TECNOLOGIES CO.,LTD. FUJITEC SHANGHAI SOURCING CENTER CO.,LTD.

#### **Europe & Middle East**

FUJITEC UK LTD. FUJITEC SAUDI ARABIA CO.,LTD. FUJITEC EGYPT CO.,LTD.

## South Asia

FUJITEC SINGAPORE CORPN. LTD. FUJITEC INC, (PHILIPPINES) FUJITEC (MALAYSIA) SDN, BOD. P.T. FUJITEC INDONESIA FUJITEC VIETNAM CO., LTD. FUJITEC INDIA PRIVATE LTD. FUJITEC (THAILAND) CO., LTD. FUJITEC LANKA (PRIVATE) LTD. FUJITEC PACIFIC, INC. (GUAM) FUJITEC MYANMAR CO., LTD.



